

Battery Maintenance and Precautions



Battery capacity deteriorates (weakens) over time.

To optimize battery life time of your Exam Reader we suggest the following:

- Disconnect charger once battery is fully charged.
- The type of battery used in this device does not have “memory”. Best charge strategy is to top it up on regular basis from e.g. 20-50% to 90-95%. To ensure you do not leave and overcharge the battery.
- Do not expose the battery to heat (above 30°C) longer than necessary.
- Do not let the battery to go completely flat.

When storing your device long term (e.g. Summer break) two key factors will effect the overall health of the battery. The environmental temperature and the percentage of the battery.

- We recommend that you do not fully charge or discharge the battery before storage so charge it to around 50%.
- Power down the device.
- Store in a cool moist -free environment less than 32 degrees Celsius.
- **Most importantly top up charge to 50% every 1 months.**